

fumasep® FS-990-PKS

General

Membrane type: Perfluorinated cation-exchange membrane – reinforced and chemically stabilized – thickness 90 µm, with low resistance, high mechanical stability, low dimensional swelling, and high stability in acidic environment.

Application: Fuel Cell application (H₂-PEMFC), PEM water electrolysis application (PEMWE) and other electrochemical applications such as flow batteries and special niche applications.

Membranes are identified by membrane type and identification number (Lot Number). Please refer to this type and identification number in case of queries.

Delivery

The membrane is the transparent foil, delivered on a backing layer (colorless rigid PET foil). Carefully separate the membrane from the backing foil. The membrane is ready for use.

Handling

Keep membrane package closed / sealed when unused. Unpack membrane only for direct use and process it immediately after opening. Store, handle and process the membrane in a clean and dust-free area. Use only new and sharp knives or blades, when cutting the membrane.

Always wear protective gloves when handling the membrane. Handle with care, be sure not to puncture, crease or scratch the membrane, otherwise leaks will occur. All surfaces which may get into contact with the membrane during inspection, storage, pre-treatment and mounting must be free of sharp edges or angles.

Pre-treatment

The membrane does not need any pre-treatment and is ready for use. Please assemble the membrane in dry form.

If you have any concerns about storage, chemical stability, and pre-treatment please feel free to contact us for further information.

FUMATECH BWT GmbH

Carl-Benz Strasse 4
74321 Bietigheim-Bissingen
Phone: +49-(0)-7142-3737-900
Fax: +49-(0)-7142-3737-999
Email: sales@fumatech.com

Technical Data Sheet - fumasep® FS-990-PKS

Physical and chemical data of fumasep® FS-990-PKS

fumasep®	unit	FS-990-PKS
membrane type		cation exchange membrane
appearance		transparent / dark yellow
backing foil		PET
reinforcement		PK
counter ion		H ⁺ form
delivery form		dry
thickness (dry)	µm	85 – 105
IEC (ion exchange capacity)	meq g ⁻¹	1.11 – 1.20
conductivity in H ₂ O at T = 25 °C in H-form ^{a)}	mS cm ⁻¹	> 50
dimensional swelling in H ₂ O at T = 25 °C in H-form ^{b)}	%	< 2
Young's modulus at 23 °C / 50 % r.h. ^{c)}	MPa	> 700
tensile strength at 23 °C / 50 % r.h. ^{c)}	MPa	> 25
Version ^{d)}	1.1	Valid from Feb 15 th 2023

a) measured in two-electrode cell (through-plane), sample activated in 10 % H₂SO₄, T = 80 °C, 24 hrs before measurement

b) reference membrane dried at ambient conditions (25 °C, 50 % r.h.), sample activated in 10 % H₂SO₄, T = 80 °C, 24 hrs before measurement

c) determined by stress-strain measurement at T = 25 °C and 50 % r.h., according to DIN EN 527-1

d) Changes without prior notices may apply.

Note: The product is not certified for drinking water applications. The data are not measured directly on the item supplied. The data sheet does not release the customer of the necessity of a goods inwards control procedure. All information included in this data sheet is based on tests and data believed to be reliable. The data do not imply any warranty or performance guarantee. It is the user's responsibility to examine performance, suitability and durability of the product for the intended purpose. FUMATECH BWT GmbH does not assume any liability for patent infringement resulting from the use of this product. Fumapem® is a trademark of company FUMATECH BWT GmbH.

Hereby, it is certified that all results of the measured item comply with the margins of the internal specification defined in the technical datasheet. All measurements and data recording are conducted in accordance with standardized procedures following the ISO 9001 certification.

FUMATECH BWT GmbH

Carl-Benz Strasse 4

74321 Bietigheim-Bissingen

Phone: +49-(0)-7142-3737-900

Fax: +49-(0)-7142-3737-999

Email: sales@fumatech.com